



2004 Chevy Silverado Crew Cab
AMSOIL Dual Remote By-Pass Filter System
Submitted by Preferred Customer Chris Baker

To install the filtration system, I began with a 7x10x1/8th steel plate. Mark up the two existing holes off the corner brace, then mark up four holes off a template to match the 1/8th plate. Cut an angle off the supplied mounting bracket. Use the angle to fill the gap between the 1/8th plate and the filter mount system. Weld four washers to the bottom of the 7x10x1/8th plate to make up the 1/16th remaining gap. Now everything should line up perfectly. Use the bolts supplied to secure oil unit to plate. I ran both lines tight to the fire wall over the transmission and sleeved them in 18 inches of radiator hose from the bottom up to prevent abrasion or heat damage. I used about six feet of hose on each line. The only added materials needed were two 90-degree fittings to come off the bottom of the oil filtration adapter. The cost of the 1/8th" plate was \$8.00."



Disclaimer: These installation examples have been submitted by sources independent of AMSOIL INC. and may not comply with AMSOIL INC. installation instructions or application recommendations.